



Installation and Removal Guide

Portlight Knob

Install

To install the cross roll pin, you can use a small hammer to tap the pin back in.



Removal

To remove the pin, please use a drill bit size 5.5mm or equivalent to take out the pin.

Our experience is usually the rolled pin is easily broken during removal and generally needs to be replaced.

