




Installation and Removal Guide Deck Hatch Hinge Pin



Install

Please check attached image, when you install the pin, please insert the pin from outside to inside. And use a hammer to gently knock it in

Removal

1. First loosen the set screw on the inside of the portlight
2. To remove the pin, When removing, knock the pin from inside towards the outside.